

## Assembly Instruction CRISPIN ROUND DINNING/COUNTER/BAR TABLE D162-DT/D162-CT/D162-BT

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the parts list and/or hardware list shown below.

PARTS LIST				
NO.	PART DESC	SKETCH	Q'TY	
Α	TABLE TOP		1	
В	TABLE SHELF	0	1	
С	TABLE LEG		4	

HARDWARE LIST				
NO.	HARDWARE DESC	SKETCH	Q'TY	
1	ALLEN BOLT (5/16"x 7/9")	<b>©</b>	16	
2	SPRING WASHER(5/16")		16	
3	FLAT WASHER (5/16"x 19mm)	0	16	
4	ALLEN KEY(M5)		1	







